

## 1 → How To Fix Samsung Note 10 Apps Crashing & Freezing

Frustrated by **samsung note 10 apps crashing**? You can use this guide to solve Samsung Galaxy Note 10 apps that keep freezing and crashing. There are a number of causes why apps keep pausing on Android difficulties, including many programs running in the background of an unmaintained program or OS, less memory causing a slower device if more apps are installed, etc.

You can try to clean the app cache or delete software updates on your Android smartphone or tablet if your Galaxy Note 10 Plus applications are stopping suddenly. Read this article to find out the best solution for samsung note 10 apps crashing.

How to fix samsung note 10 apps crashing Issues

Start by long pressing the power button on your Note 10 and tapping the restart option to restart it. Open the app when the device has restarted and look for the resolved problem. Use the troubleshooting techniques listed below to resolve samsung note 10 apps crashing.

Uninstall App Updates to fix Samsung Note 10 Apps Crashing

To resolve issues with apps, ensure that the app is updated to the most recent version. If an app suddenly stops functioning, consider uninstalling any recent updates and then updating with the most recent version.

Step 1: Launch the Settings app.

Step 2: Select Apps.

Step 3: Decide which app you would like to remove the update from.

Step 4: Tap the More button at the top right corner of the screen.

Step 5: Select Uninstall updates.

The factory version of the app will take its place as a result. Your device will be cleared of all app data.

Step 6: Select OK.

Restart your device now, then update it using the suggested options.

Play store > Three horizontal lines at upper left corner > My apps & games > Update all

Clear App Cache

Try clearing the app cache on your Note 10 if the app causes your device to lag or freezes. Data from your device's apps will be momentarily deleted.

Step 1: Launch the Settings app.



